

# MAPEI ADHESIVE RECOMMENDATION



## Flooring installation

Flooring	Adhesives	Trowel	Consumption	Time for light foot traffic
EGGER Aqua+ Laminate	<b>ULTRABOND ECO S968 1K</b>	TKB B11	approx. 1.000 g/m <sup>2</sup>	24 hours
EGGER Design GreenTec	<b>ULTRABOND ECO S968 1K</b>	TKB B3	approx. 800 g/m <sup>2</sup>	24 hours

## Substrate preparation

Waterproofing barrier, if required*	<b>MAPEGUARD WP 200 + MAPEGUARD WP ADHESIVE</b>				
Levelling compound	<b>ULTRAPLAN XTRA</b>	<b>ULTRAPLAN XTRA</b>	<b>PLANITEX FAST</b>	<b>ULTRAPLAN XTRA</b>	<b>PLANITEX FAST</b>
Primer	<b>PRIMER MF EC PLUS</b>	<b>ECO PRIM T PLUS</b> 1:3 diluted with water	<b>ECO PRIM T PLUS</b> 1:2 diluted with water	<b>ECO PRIM GRIP PLUS</b>	<b>ECO PRIM T PLUS</b> 1:1 diluted with water
Mechanical preparation	e.g. clean, abrase, vacuum, depending on the substrate				
Substrate	Concrete	Cement screed	Calciumsulphate screed	Existing ceramic tiles	Asphalt screed

\* We recommend to consult the MAPEI Technical Assistance.

This recommendation contains products that are sold in Germany. For other products, please contact the local MAPEI subsidiary; contacts available at [www.mapei.com](http://www.mapei.com).

The mentioned products describe the application in an abbreviated form. Please note the corresponding Technical Data Sheets.